



SEAMLESS FLOORING SYSTEMS

LAMINATE & HYBRID (LOOSE LAID) FLOORING OVERLAY ON TIMBER SUBFLOORS WET ROOMS CONTAINMENT INSTALLATION SYSTEM ALTERNATIVE SOLUTION- E3/AS1 BUILDING CODE - INTERNAL MOISTURE FOR FINISHES TO FLOORS:

Containment - water from accidental overflow from a sanitary fixture that "could damage an adjoining household unit or other property". The affected areas are defined as having a sanitary fixture (e.g. toilet, sink, shower or bath) or sanitary appliance (e.g. washing machine or dishwasher.)

Must be read in conjunction with E3/AS1 November 4th 2021 Building Code. The following information is only to assist in the Alternative Solutions options for the installer. It is essential the Laminate supplier provides their own documentation as to the floorcoverings suitability as required by E3/AS1.

- 1 Composite Timber Subfloor Sheet Type: Particle Board/Plywood/Strand Board.
NB: For Cross Laminate Timber (CLT)/Parallel Laminated Timber (PLT) Type Construction Panel Subfloors: Contact Gilt Edge Technical for project specific system advice and selections.
- 2 RLA Flexi-Seal P.U.D. Waterproof Membrane pre-primed with Roberts Universal Acrylic Primer.
- 3 For composite timber sheet subfloors Uzin PE280 primer / Uzin NC157 SP levelling compound at 3mm thickness applied over primed Flexi-Seal PUD Waterproof Membrane.
- 4 Proprietary Moisture Resistant Underlayment (as per systems recommended by the Laminate or Hybrid Flooring Supplier.)
- 5 Interlocking Laminate or Hybrid Flooring System.

