



STRIPPER SELECTION GUIDE

	Rubber	Rubber	Rubber	Rubber	Cork	Flotex	Resilient	PVC Backed	Bitumen Backed	Direct Stick	Timber &	Timber &	Ceramic	Ceramic Tile	VCT	
	4mm	6mm	8mm	15mm	Tiles		Flooring	Carpet tiles	Carpet tiles	Carpet	Std Adhesive	Heavy Adhesive	Tiles	Adhesive	Tiles	
RO:1																
Roll:2																
Bully Stripper																
Roll:1 Blades																
1718450 350x80x2mm Hardened U Blade up																
1718460 350x80x2mm Hardened U Blade down																
1718560 300x60x2mm																
1718570 300x70x2mm																
1718420 350x80x2mm																
1718585 250x180x6mm Hardened flat angle																
1718588 250x180x6mm Hardened steep angle																
1718589 250x180x6mm Hardened medium angle																
1718592 60mm																
1718594 80mm																
1718596 100mm																
1718598 120mm																

KEY: ■ YES ■ NO ■ MAYBE

	Rubber	Rubber	Rubber	Rubber	Cork	Flotex	Resilient	PVC Backed	Bitumen Backed	Direct Stick	Timber &	Timber &	Ceramic	Ceramic Tile	VCT
	4mm	6mm	8mm	15mm	Tiles		Flooring	Carpet tiles	Carpet tiles	Carpet	Std Adhesive	Heavy Adhesive	Tiles	Adhesive	Tiles
ROLL:2 Blades															
1718400 250x80x2mm Hardened															
1718430 250x80x2mm Hardened U Blade up															
1718440 250x80x2mm Hardened U Blade down															
1718589 250x180x6mm Hardened medium angle															
1718596 100mm															
1718529 60mm															
Bullystripper Blades															
1714580															
1714581 Hardened															
171592 U Blade Hardened															

KEY: ■ YES ■ NO ■ MAYBE

GENERAL GUIDE TO USING BLADES

- 1 - Use this as a reference only based on our testing and knowledge.
- 2 - If you are not using a U blade pre cut the flooring into strips the harder the floor is stuck the smaller strips you will need to cut.
- 3 - Try the blade both ways for best results.
Generally you will find if you have a soft substrate ie timber or poor quality leveling compound the bevel down will not dig into the floor so much.
- 4 - For VCT tiles, sweep in front of the RO2 unit as you go. This will allow you the most traction.

