

Fibre-reinforced PVC luxury flooring and rubber adhesive

UZIN KE 66

Dispersion-based adhesive for PVC luxury flooring, rubber flooring in sheets and tiles up to 4 mm and PVC flooring.

MAIN APPLICATION FIELD:

- ▶ PVC luxury vinyl tiles
- ▶ PVC and CV floor coverings in sheets and tiles
- ▶ rubber floor coverings in sheets and tiles up to 4 mm (e.g. norament®, noraplan® or noraplan® acoustic)
- ▶ textile floor coverings in health care institutions

SUITABLE ON / FOR:

- ▶ absorbent and levelled substrates
- ▶ warm water underfloor heating systems
- ▶ exposure to castor wheels in accordance with DIN EN 12 529
- ▶ wet shampooing and spray extraction cleaning according to RAL 991 A2
- ▶ suitable for commercial and industrial locations
- ▶ areas subject to high temperatures



PRODUCT BENEFITS/FEATURES:

UZIN KE 66 is a wet-set, dispersion-based adhesive with a short open time and excellent adhesion. The highly shear-resistant and fibre-reinforced adhesive reduces the formation of pressure marks on the floor covering. For interior use.

- ▶ short waiting time
- ▶ excellent working properties
- ▶ very low consumption
- ▶ CO₂-neutral product*


*Internally calculated value along the life cycle stages A1-A3 (cradle to gate)



TECHNICAL DATA:

Packaging	plastic bucket
Pack size	14 kg
Shelf life	min. 12 months
Colour, wet	beige
Colour, dry	beige
Consumption	170 - 260 g/m ²
Open time	tiles, planks: 5 - 10 minutes** / sheets: 20 - 25 minutes**
Working time	approx. 20 Minutes**
Minimum application temperature	15 °C at ground level
Loadable	after approx. 24 hours**
Joint sealing	after 24 hours**
Final strength	after approx. 3 days**

**At 20 °C and 65% relative humidity, depending on the type of floor covering and the absorptency of the substrate.



SUBSTRATE PREPARATION:

The substrate must be sound, load-bearing, dry, free from cracks and materials (dirt, oil, grease) that would impair adhesion. The surface must be vacuumed, primed and smoothed. Suitable primers and compounds can be found in the UZIN Product Guide. Test the substrate in accordance with applicable standard or notices and report any deficiencies. Allow the primer and levelling compound to dry completely.

The datasheets for other used products have to be observed.

APPLICATION:

1. Apply an even coat of adhesive onto the substrate using a suitable notched trowel and allow to dry partially according to the application amount, the indoor climate, the absorbency of the substrate and the type of floor covering. Do not apply more adhesive than can be laid with good transfer onto the back of the covering within the working time.
2. Install the floor covering within a short open time and ensure the adhesive ridge is pressed out. Rub in or roll over and apply weight against any flooring deformation. Ensure that air is not trapped under the covering. Allow the area to rest for 20 minutes and then roll over again and rub in at edge and seams.
3. Remove adhesive residues while fresh with water.

CONSUMPTION INFORMATION:

Zahnung	Belagsart/Belagsrücken	Verbrauch* ca.
A2	PVC LVT, PVC and CV coverings	280 g/m ²
A2	Rubber sheets and tiles	290 g/m ²
A1	PVC design floor coverings with smooth backing	240 g/m ²

*At 20 °C and 65% relative humidity with tempered adhesive buckets.

IMPORTANT NOTES:

- ▶ A shelf life of 12 months when stored in moderately cool conditions, in the original packaging. Frost-resistant down to - 8 °C. Carefully and tightly reseal opened containers and use the contents quickly. Allow containers to come to room temperature before use.
- ▶ Best applied between 18 - 25 °C, with the floor temperature above 15 °C and relative air humidity below 65%. Low temperatures and high air humidity lengthen the working and drying time. Whilst high temperatures and low air humidity shorten the working and drying time.
- ▶ Humid substrates may cause secondary emissions and odours. Therefore, ensure the compound is dry before applying the adhesive.

- ▶ Installations onto substrates with old adhesive residues may cause interactions and lead to unpleasant odours. Ideally these should be removed completely. In all situations adhesive residues must be remedied via the use of primers and coatings of compound at least 3 mm thick.
- ▶ Before installing, the floor covering must be adequately acclimatised to the indoor climate and free from tension.
- ▶ UZIN KE 66 can be used in areas subject to high temperatures up to 50 °C. However if a floor covering is being installed in areas with extreme temperatures, for example, a south facing building with large windows which could magnify the temperature, a reaction resin adhesive (e.g. UZIN KE 68 or UZIN KR 430) is recommended.
- ▶ Strong deformation of the roll ends, hanging bays, extremely raised edges or strong curvatures must be weighed down during the adhesion.
- ▶ Please check the adhesive recommendations (online) or obtain application advice when installing chlorine-free floor coverings.
- ▶ When sealing, cleaning and maintaining the floor covering, products from the UZIN Care range can be used (UZIN Basic Cleaner, UZIN Turbo Protect Plus, UZIN Resilient Care, UZIN Refresher). For further information please refer to the product data sheets.
- ▶ Follow the generally acknowledged rules of the trade and technology for the installation of floor covering in respective of the applicable national standards (e.g. EN, DIN, OE, SIA, etc.)

SEALS OF QUALITY & ECOLABELS:

- ▶ Solvent-free
- ▶ EMICODE EC 1 PLUS / Very low emission
- ▶ DE-UZ 113 / Environmentally friendly because of low emissions

COMPOSITION:

Polymer dispersion, preservation agents, mineral aggregates, additives and water.

PROTECTION OF THE WORKPLACE AND THE ENVIRONMENT:

Solvent-free. Use of barrier cream and ventilation of the work area are recommended. When fully dried, has a neutral odour and presents no physiological or ecological risk. Basic prerequisites for best possible indoor air quality following floor covering work are conformity to standards of the working conditions, as well as thoroughly dry substrate, primer and smoothing compound.

DISPOSAL:

Where possible, collect product residues and re-use. Do not allow dispersal into drains, sewers or ground. Empty, scraped and drip-free containers are recyclable. Containers with liquid residue, as well as the liquid product, are classed as Special Waste. Dried product residues are classed as Construction Waste.